



Follow the instructions to add a panel of useful phone numbers to a panel in the bottom left corner of Sectra's Information Window:

The screenshot displays the Sectra software interface. The top menu bar includes File, Edit, View, Tools, Demonstration, Status, Window, Parked Examinations, and Help. Below the menu bar are various tool icons and a search bar. The main interface is divided into several panels. On the left, there is a 'FAVORITES' section with items like '3. On Call Resident' (66), 'Assigned to me' (0), '2. Neuro A' (12), '3. Neuro B' (330), 'My Prelims' (0), and 'History' (100). Below this is the 'ALL WORKLISTS' section, which is expanded to show 'System Worklists' and 'Role Worklists'. The 'System Worklists' section includes items like 'Mismatched', 'Clinic (Last 2 Days)', 'ED', 'Hospital (Last 2 Days)', 'Mismatched Special', 'Missing RIS', 'Modality (Last 1 Week)', 'Outside Studies', 'Public Folders', and 'Research'. The 'Role Worklists' section includes 'Breast Imaging Radiologist', 'Breast Imaging Resident', 'MDT Conferences', 'PACS User', 'QA Supervisor', 'Radiologist', and 'Resident'. The 'User Worklists' section includes 'History', 'Search Results', and 'Imported'. The main area of the interface is currently empty, displaying 'No worklist selected' and 'No examinations'. In the bottom left corner, a panel titled 'Resident (handheld): 38149' is visible, containing a list of phone numbers. This panel is highlighted with a red dashed circle. The phone numbers listed are: ED: 30100, ED Charge: 38128, ED Triage: 38129, CT 1: 34198 & 31679, CT 2: 34199 & 31659, CT 3: 34197 & 31722, CT 4: 34196 & 31783, MRI (OPB): 53468, MRI #1 & 2: 34417, MRI #3: 32677, MRI Rogers (3T): 57693, MRI Rogers (main 1.5T): 57691, Sono: 31899, Sono Tech: 34191, Strout/Kircher: 38149/34440, Prefixes: 214-645- for 5***; 214-590- for 2*** ; 214-633-***** for 3***, and IT: 87600.


1. Click on **Tools** in the toolbar of Sectra's "Information Window" (i.e. main window) and click on **Options**



2. Click on your name, then click on **Continue >**



3. Click on the **Advanced Configuration** tab, then under **Information Window**, look for **Worklists and Search**. Now click on the **Info Panel**




4. Now on the right panel, click on **URL** and then **Edit**.

5.




6. Copy and paste the following address to the opened window and click on **OK**:


<https://sectra.utswrads.com>



7. Now choose **Visible at startup** and click on **Edit**



8. In the opened window, choose **True** from the drop down menu and click on **OK**



9. Now click on **OK**. Sectra has to be closed and opened again for the changes to take effect.

To suggest phone numbers to be added to this list, contact admin@utswrads.com